



	<b>Part Number</b>	<b>Description</b>
<b>1</b>	799360	Motor housing, SX top section
<b>1</b>	799359	Motor housing, DX top section
<b>2</b>	713009	Manual release key, 412
<b>3</b>	717110	Flange, protective cover, 412 SX
<b>3</b>	717109	Flange, protective cover, 412 DX
<b>4</b>	736060	Cylinder assembly, 412 slide on
<b>5</b>	727148	End cap, 412 protective cover SX
<b>5</b>	727147	End cap, 412 protective cover DX
<b>6</b>		
<b>7</b>	727216	Protective cover, 412
<b>8</b>	722298	Protective cover support, 412
<b>9</b>	716056	Motor housing, bottom section, 412
<b>10</b>		Motor
<b>11</b>		Rotor
<b>12</b>	710919	Strain relief, 412
<b>13</b>	390009	Skin pack, 412 (1 pack = 2 operators)

**Figure 16. 412 Exploded view and parts list**