
10 11 9 12 IR 1L (Not Shown)





Overhead Gate Hardwar

Overhead Jamb Track Hardware List

1R	Power Arm - Right		HARDWARE
1L	Power Arm - Left		
2	Inner Thrust Bearing	23	Connecting Link
3	Main Pivot Bushing	24	Connecting Link Bushing (x2)
4R	Main Pivot Bracket - Right	25	Connecting Link Bolt 3/8"
4L	Main Pivot Bracket - Left	26	Connecting Link Bolt 1/2"
5	Outer Thrust Bushing	27	Connecting Link Nylon Nut 3/8"
6	Flat Washer 3/4"	28	Connecting Link Nylon Nut 5/16"
7	Nylon Threaded Nut 3/4"	29	Spring End With Saddle
8	Label 2" X 11"	30A	Spring - 3"
9	Lower Pivot Bushing (x2)	30B	Spring - 4"
10	Lower Pivot Pin (Tapered)	30C	Spring - 5"
11	Lower Pivot Pin Retaining Clip	31	Spring End With Nut
12	Lower Pivot Bracket	32	Spring Adjusting Bolt 1/2"
13	Kicker Roller Bracket	32A	Spring Adjusting Bolt 5/8"
14	Kicker Roller Shaft	33	Spring Adjusting Bolt 1/2" Washer
15	Kicker Roller	33A	Spring Adjusting Bolt 5/8" Washer
15A	Kicker Roller w/ Shaft	34	Tracks 8'
16	Kicker Roller Retaining Clip (x2)	35	Label 2.5" X 2" Warning Bracket
17	Track Roller Bracket		
18	Track Roller Shaft		THE CATE OF
19	Track Roller 3"		AUTOMATIC GATE OPERATORS
19A	Track Roller w/ Shaft		A DE A BELA ®
20	Track Roller Collar		

Types And Sizes Of Jamb Track Hardware

Track Roller Washer

Track Roller Retaining Clip
Main Spring Bracket
Spring Bracket Hardware

	Weight	Width	Height	
Short Set	350lbs	19'	6'6"-7'	
Standard Long	350lbs	19'	7'-7'6"	
Standard Jumbo	350lbs	22'	7'-8'	
Heavy Jumbo	550lbs	22'	7'-8'	
Long Heavy Jumbo	650lbs	22'	9'-10'6"	

Tilt Up Jamb Track HardwareTilt Up Jamb Track Hardware

WARNING

All Jamb Track Hardware <u>must be installed and maintained by technicians who are experienced and well trained</u>. Do not try to learn to install Jamb Track Hardware only by reading the instructions, it can not be done. You must be taught in the field by those you trust and have been installing experience. To maintain Jamb Track Hardware you must have years of experience working with an experienced installer who has taught you the proper way to maintain overhead gates and Jamb Track Hardware.

WARRANTY

All-O-Matic, Inc jamb track hardware is warranted against defects in materials and workmanship for two years. Any part or parts of hardware found to be defective within this period shall, at the manufacturer's option, be repaired or replaced free of charges, F.O.B. Our factory.

The above warranty is in lieu of all other warranties, expressed or implied, and shall be



ALL-O-MATIC INC North Hollywood, CA 91605

