



AXPO PUSH-TO-OPEN BRACKET KIT

■ INSTALLATION

Two Push-To-Open brackets are required for each operator arm. This means that a single gate opener kit will require one AXPO kit and a dual gate opener will require two AXPO kits, or a total of four brackets.

PLEASE REFER TO YOUR GATE OPENER INSTALLATION MANUAL FOR DETAILS ON INSTALLING THESE BRACKETS.

WARRANTY:

GHOST CONTROLS® AXPO Push-To-Open Brackets are warrantied for 18 months with proof of purchase. An additional 6 month warranty is available at NO COST if you register your item within 30 days of purchase on www.ghostcontrols.com/register. See warranty terms on www.ghostcontrols.com/warranty.

For more information on GHOST CONTROLS® Automatic Gate Openers and Accessories please visit our website at www.ghostcontrols.com.